



See [antenna\\_simulation.readme](#) for details

R6: a shunt, if you want to measure input current  
 Close solder jumpers (Jx) if you don't populate components  
 NP = Not populated, footprint is there if you need to do some adjustments

Make space for some more capacitors and resistors than shown here  
 so you can mix values to the desired outcome

